

FIRE DOOR INSTALLATION CHECKLIST

- DOORS MUST BE STORED FLAT AND DRY
- DOES THE DOOR FRAME HAVE A 25MM STOP?
- IF YOU ARE INSTALLING A PAIR, IS THE DOOR 45MM+?
- THERE IS A SMALL HOLE IN THE TOP OF EACH DOOR INDICATING THE HINGE SIDE. ENSURE THE DOOR IS INSTALLED WITH THIS AT THE TOP.
- ALL HARDWARE INSTALLED MUST BE ON THE MANUFACTURERS APPROVED HARDWARE LIST. CALL SUREFAB IF YOU REQUIRE A COPY.
- A MAXIMUM CLEARANCE OF 15MM BETWEEN THE DOOR AND THE NON-COMBUSTIBLE SURFACE (E.G. SLAB) AND 3MM AT THE TOP IS RECOMMENDED.
- A MINIMUM OF 3 HINGES ARE TO BE USED TO HANG A FIRE DOOR
- HAS THE FRAME BEEN BACKFILLED?
- DOORS CANNOT BE GUARANTEED IF PAINTED IN A DARK COLOUR OR EXPOSED TO DIRECT SUNLIGHT OR WEATHER